


# INVISIPURE

## IP-1402

English

## Introduction

Thank you for purchasing the IP-1402 ultrasonic facial moisturizer. The unit has a 14ml water tank capacity and uses ultrasonic technology to moisturize your skin throughout the day.



## Product structure

- a. Sliding on / off switch
- b. Ultrasonic spray nozzle
- c. Water tank cover
- d. LED indicator light
- e. Battery cover

## Warnings:

- Do not touch or block the mist outlet.
- Do not let children play with the unit.
- Do not refill the unit when its turned on.
- To avoid fire hazard, do not immerse in water.
- Do not use the unit if you see any deterioration or corrosion on the unit.
- Always turn off the unit when not in use.
- Turn on the unit in the upright position only.
- Do not use essential oils. Do not use chemicals or detergents.
- Only use cool filtered water. Do not use warm or hot water.
- Use only AAA size alkaline batteries. Do not use lithium batteries.
- Check the polarity mark on the unit and properly install batteries.
- Check for leaks every time you fill the unit. Do not use unit if leaking occurs.



## Operating Instructions:

- Open battery cover and install 2 x AAA size alkaline batteries. Check the polarity before installation.
- While facing the front of the unit, turn top cover to the right approximately 1/4 turn to remove the cover.
- Carefully pour in the water. Do not overfill and leave 1/4 inch of space from the top of the water tank.
- Place the cap on the unit. Align the cap by matching the two side notches. Turn the cap to the left approximately 1/4 turn to the left.
- To turn on the unit, slide the power switch down. The power and mist output will automatically shut off after 45 seconds. To turn off before this time, you may slide the power switch up.
- If the unit turns on and the blue light blinks or mist comes out intermittently, please replace the batteries.



## Maintenance Instructions:

- Before cleaning, turn off the unit. Remove the top cover and rinse under running water. Dry with a soft cloth towel.
- Remove excess water from the tank and refill and empty the tank with clean water a few times. Use a soft cloth towel to dry the tank. If you notice any odors, you may mix a small amount of distilled vinegar and water and fill the tank. Empty the tank after a few minutes and refill the tank with clean water and empty again. Use a soft cloth towel to dry the tank.
- We do not recommend using essential oils or cosmetic products in the unit as it may damage the unit.
- Check the battery compartment and make sure there is no water or corrosion. If this occurs, please stop using the unit.



## Troubleshooting:

If your unit is not working correctly please check the following causes.

Problem	Solution
No mist is coming out while on.	Turn off and turn the unit back on. Check if there is water in the tank. Check and replace batteries.
Blue light is blinking while on.	Replace batteries with new batteries.
Water is leaking.	Confirm cover is on and closed properly. Check for cracks around cover and water tank. If leaking continues, stop using the unit.
Weak mist output.	Check if tank is empty. Fill with water. Replace batteries. Use a cotton swab and gently clean the mist outlet.